

NOTE:

For the BUS connection Use a shielded pair cable twisted like BELDEN 8762 (max 500 m).

SW: 28162100B


RIF.	COM. N°	DESCRIZIONE	ESEGUITO	DATA
①	AD 7527	PRIMA ESECUZIONE	MC	19.03.15
EWMET S.P.A.		DENOMINAZIONE		
A termini di legge e' vietato riprodurre o comunicare a terzi il contenuto del presente disegno. Proprieta' riservata.		ELECT DIAGRAM PCDC 09_10T/1H		
CODICE		FOGLIO	NOTE	
E60001120		1/8	PCDC board	

Key for electric diagram 9. 10T/1H for PCOC board

ID1	= External input: high temperature	CC	= Boiler interlock
ID2	= External input: low temperature	CF	= Chiller interlock
T/H 1	= Room temp./humidity sensor ZONE 1	RP	= Pump A relay
B5	= remote ON/OFF	RS	= Summer/Winter relay
B6	= Boiler alarm	R_AG/AUX	= Frost protection relay/ Periodic auxiliary function relay
B7	= Chiller alarm	T1	= Zone 1 electrothermic head
B8	= Summer/Winter selector	RD	= Interlock Realy Dehumidifier
T man	= Flow temperature sensor	Y/Y2	= 0-10V signal for the mixing valve proportional servomotor
Text	= Outdoor temperature sensor	BUS	= Bus for connection with expansion board MOD_Z1

NOTE:

- Output J3 - Boiler interlock - Contact rating 8 A - 250 Vac - $\cos\phi = 1$
- Output J4 - PGD1 Large remote terminal connection via 6-wire telephone cable
- Output J10 - Chiller interlock - Contact rating 8 A - 250 Vac - $\cos\phi = 1$
- Output J11 - Contact rating 5 A - 250 V AC - $\cos\phi = 1$
- Output NO3 - Frost protection digital output, closed contact: frost protection function in progress. If the digital output is enabled from the advanced menu it is used for the periodic auxiliary function, closed contact: auxiliary function in progress. (The logic is invertible from the advanced menu)
- Output NO7 - Summer/Winter digital output, closed contact: Winter. (The logic is invertible from the advanced menu)
- Back-up relay always recommended. Also use change-over relays if you are using commons with different voltages
- Digital input ID1 - When the contact closes it requests high temperature from the thermostat
- Digital input ID2 - When the contact closes while the function is in progress, it requests low temperature from the thermostat (if enabled)
- Digital input B5 - Allows the system to be switched on or off remotely, when selected in the PCOC menu
- Digital input B6 - For connection of a boiler alarm circuit, where fitted by the boiler manufacturer
- Digital input B7 - For connection of a chiller alarm circuit, where fitted by the chiller manufacturer
- Digital input B8 - Allows the system to be switched in heating or cooling mode remotely, when selected in the PCOC menu
- The logic of the inputs can be inverted from the advanced menu
- For PCOC regulator input and output connections, use cables with a section that is proportional to the load (1,5 mm²)
- The current supply for the regulator and the supply for the 0-10V servomotor must be galvanically isolated, using either two transformers or one with two independent secondary circuits.
- If dehumidification is only carried out during the summer season every dehumidifier should be switched on from a corresponding electrothermic head equipped with a micro switch. When there is a request for dehumidification the electrothermic head is powered. When it opens the micro switch closes, in this way the dehumidifier switch on. (See the following diagram by way of example)




WARNING!

For graphic the common terminals of the sensors are shown schematically connected at the most convenient points. When wiring, run all leads of the probes to the terminals of the adjustment device and make the common connections at that point. This measure prevents electromagnetic disturbances which compromise correct signal transmission. Avoid running the cables of the sensors and of the digital inputs together with the power cables. It is advisable to use shielded cables for the connection of the sensors.

IMPORTANT!

T/H temperature and humidity sensors: before closing the T/H probes, check that jumpers DP1 - DP2 are positioned as in the figure.

This operation enables output "out H" of the probe with signal 4/20 mA for correct measurement of humidity.



out H = humidity output (0/1 Vdc o 4/20 mA)
M = reference for both power supply and outputs
+ (G) = power supply (12/24 V AC or 9/30 V DC)
ntc = NTC resistive output
DP1 = OFF
DP2 = ON

EMMET S.P.A. <small>A termini di legge e' vietato riprodurre o comunicare a terzi il contenuto del presente disegno. Proprieta' riservata.</small>	DENOMINAZIONE ELECT DIAGRAM PCOC 09_10T/1H		
	CODICE E60001120	FOGLIO 2/8	NOTE PCOC board

Key for electric diagram 9. 10T/1H for EXPANSION board MOD_Z1

To configure the PCOE module as expansion MOD_Z1 set 1 as the serial address, see diagram on how to set the DIP switches

T	= Room temperature sensors	T2	= Zone 2 electrothermic head
		T3	= Zone 3 electrothermic head
BUS	= Bus for the connection from PCOC to expansion board	T4	= Zone 4 electrothermic head
	MOD_Z2	T5	= Zone 5 electrothermic head


NOTES:


- Output J5, J6, J7, J8 - Contact rating 8 A - 250 V AC - $\cos\phi = 1$
- For regulator input and output connections, use cables with a section that is proportional to the load (1.5 mm²)

WARNING!

For simplicity the common terminals of the sensors are shown schematically connected at the most convenient points.
When wiring, run all leads of the probes to the terminals of the device and make the common connections at that point.
This measure prevents electromagnetic disturbances which compromise correct signal transmission.

Avoid running the cables of the probes and of the digital inputs together with the power cables.
It is advisable to use shielded cables for the connection of the sensors.

 EMMET S.P.A. <small>A termini di legge e' vietato riprodurre o comunicare a terzi il contenuto del presente disegno. Proprieta' riservata.</small>	DENOMINAZIONE ELECT DIAGRAM PCOC 09_10T/1H		
	CODICE E60001120	FOGLIO 4/8	NOTE MOD_Z1 board



NOTE:

For the BUS connection Use a shielded pair cable twisted like BELDEN 8762 (max 500 m). Connecting chain, in-out mode, between the boards according to the polarity.

RIF.	COM. N°	DESCRIZIONE	ESEGUITO	DATA
①	AD 7527	PRIMA ESECUZIONE	MC	19.03.15
EMMET S.P.A.		DENOMINAZIONE		
A termini di legge e' vietato riprodurre o comunicare a terzi il contenuto del presente disegno. Proprieta' riservata.		ELECT DIAGRAM PCDC 09_10T/1H		
CODICE		FOGLIO	NOTE	
E60001120		5/8	MOD_Z2 board	

Key for electric diagram 9. 10T/1H for EXPANSION board MOD_Z2

To configure the PCOE module as expansion MOD_Z2 set 2 as the serial address, see diagram on how to set the DIP switches

T	= Room temperature sensors	T6	= Zone 6 electrothermic head
		T7	= Zone 7 electrothermic head
BUS	= Bus for connections from expansion board MOD_Z1 to expansion board MOD_Z3	T8	= Zone 8 electrothermic head
		T9	= Zone 9 electrothermic head

NOTES:


- Output J5, J6, J7, J8 - Contact rating 8 A - 250 V AC - $\cos\phi = 1$
- For regulator input and output connections, use cables with a section that is proportional to the load (1.5 mm²)

WARNING!

For simplicity the common terminals of the sensors are shown schematically connected at the most convenient points.
When wiring, run all leads of the probes to the terminals of the device and make the common connections at that point.
This measure prevents electromagnetic disturbances which compromise correct signal transmission.

Avoid running the cables of the probes and of the digital inputs together with the power cables.

It is advisable to use shielded cables for the connection of the sensors.

 EMMET S.P.A. <small>A termini di legge e' vietato riprodurre o comunicare a terzi il contenuto del presente disegno. Proprieta' riservata.</small>	DENOMINAZIONE ELECT DIAGRAM PCDC 09_10T/1H		
	CODICE E60001120	FOGLIO 6/8	NOTE MOD_Z2 board

Key for electric diagram 9. 10T/1H for EXPANSION board MOD_Z3

To configure the PCOE module as expansion MOD_Z3 set 3 as the serial address, see diagram on how to set the DIP switches

T = Room temperature sensors

T10 = Zone 10 electrothermic head

BUS = Bus for connections from expansion board MOD_Z2

NOTES:

- Output J5, J6, J7, J8 - Contact rating 8 A - 250 V AC - $\cos\phi = 1$
- For regulator input and output connections, use cables with a section that is proportional to the load (1.5 mm²)

WARNING!

For simplicity the common terminals of the probes are shown schematically connected at the most convenient points.

When wiring, run all leads of the probes to the terminals of the adjustment device and make the common connections at that point.

This measure prevents electromagnetic disturbances which compromise correct signal transmission.


Avoid running the cables of the sensors and of the digital inputs together with the power cables.

It is advisable to use shielded cables for the connection of the sensors.

GENERAL NOTES ON THE POWER SUPPLY

It is possible to power all of the boards (PCOC, MOD_Z1, MOD_Z2, MOD_Z3) with a single transformer providing a power supply of 24 Vac $\pm 10\%$ -15% 50/60 Hz and a power of at least 38 VA. Alternatively, it is possible to use a transformer that provides a power supply of 28Vdc $\pm 10\%$ -20% and a power of at least 29 W. Use the same polarity (G, G0) for the power supply for all the boards.

The power supply for PCOC and PCOE controls must be separate from the power supply of the 0-10V servomotor(s)

 <small>A termini di legge e' vietato riprodurre o comunicare a terzi il contenuto del presente disegno. Proprieta' riservata.</small>	DENOMINAZIONE ELECT DIAGRAM PCOC 09_10T/1H		
	CODICE E60001120	FOGLIO 8/8	NOTE MOD_Z3 board